DRIVER INSTALLATION:

Windows XP/ Vista/ 2000/ Server 2008&2003/ Win7/ 8 (32&64-Bit) :

Windows will recognize a new "FT232R USB UART" and open the hardware assistant. Please choose manual installation and put the driver CD into your CD-Rom drive. Enter the Path "D:\USB_to_IO\FTD\((32_64bit)\Win7_XP_Vista_2008_2008R2_2003_2000". into the box for the Path/Source and click at >next/continue<. Now Windows search for the drivers in the specified directory. Follow the hardware assistant and finish the installation. If Windows recognizes other new devices repeat the above described steps. Attention! Restart Windows in any case after installing the drivers.

CHECK THE INSTALLED DRIVER:

Click at Start<>Run< then enter "compmgmt.msc" and click at >OK<. In the windows that open select >Device Manager<. Under "Ports (COM and LPT)" you should find one more new "USB Serial Port, as sample (COM5). If you see this or similar entries the module is installed correctly.

INSTALL THE PERIPHERAL DEVICE:

The speed from the serial ports can be set to the maximum baud rate of 115.2Kbaud. With double click select for example >Device manager< > USB Serial Port (COM5)

 Now you can select the different settings of baud rate, stop/start-bits etc. This setting you can use also for the other COM ports.

Windows 98/98SE/ME:

Windows will recognize a new "FT232R USB UART" and open the hardware assistant. Please choose manual installation and put the driver CD into your CD-Rom drive (as sample D:) . Now enter the Path "D:\USB_to_IO\FTD\\WinsB_\ME" into the box for the Path/Source and click at >next/continue<. Now Windows search for the drivers in the specified directory. Follow the hardware assistant and finish the installation. If Windows recognizes other new devices repeat the above described steps. Attention! Restart Windows in any case after installing the drivers.

CHECK THE INSTALLED DRIVER:

Click at Start<>Run< then enter "compmgmt.msc" and click at >OK<. In the windows that open select >Device Manager<. Under "Ports (COM and LPT)" you should find one more new "USB Serial Port, as sample (COM3). If you see this or similar entries the module is installed correctly.

CHANGE PORT NUMBER:

If you like to change the port number for example COM 3 to COM 5, open the **>Device**Manager< click at **>COM3<**, **>Settings<** and then **>Advance<**. There you can change between COM 3 to 256.

LINUX:

There are drivers available for Linux. The drivers are located in the folder "D:\USB_to_IO\FTD\Linux x86_64" on the driver CD. They are supported by the most versions of Linux. Because each individual distribution and kernel version of Linux is different, sadly we cant provide a installation instruction. Please refer to the installation manual for standard IO ports from your Linux version!

MAC:

There are drivers available for MAC. The drivers are located in the folder "D:\USB_to_IO\FTDI\MAC OSX or Mac_OS_9.8" on the driver CD. They are supported by the most versions of MAC OS. Because each individual version of MAC OS is different, sadly we cant provide a installation instruction. Please refer to the installation manual for standard IO ports from your MAC OS version!



Bedienungsanleitung

EX-1301-2F

Vers. 1.0 / 30.01.2013

AUFBAU:



BESCHREIBUNG & TECHNISCHE DATEN:

Die EX-1301-2F ist ein Kabel zur Umsetzung von USB auf eine RS-232 Schnittstelle mit FIFO 16C550 Ports für den direkten Anschluss von High Speed Seriellen RS-232 Peripherie Geräten (z.B. Modem, Plotter usw.) Die EX-1301-2F hat einen 9 Pin Buchsen Anschluss und kann somit direkt an das Endgerät angeschlossen werden. Das USB Modul ist Hot Plug & Play fähig. Für die Einstellungen der I/O Adressen und Interrupts sind keine Jumper und Einstellungen notwendig. Sie werden vom System BIOS und beim Installieren des Betriebsystems automatisch vorgenommen.

Kompatibilität: USB 1.1 & 2.0 Anschluss

Betriebssysteme: WIN 9.x/ ME/ 2000/ XP/ Server 2003/ Vista/ 7/ 8Linux/ MAC

Anschlüsse: 1 x 9 Pin Sub-D Stecker, 1 x USB A-Buchse

Lieferumfang: EX-1301-2F, Anleitung, CD,

Zertifikate: C€ / FCC / RoHS / WEEE

DE97424562 / WHQL

JUMPER EINSTELLUNG & ANSCHLÜSSE:

DB 9F:



Seriell 9 Pin D-SUB Buchse:					
Pin	Signal	Pin	Signal	Pin	Signal
1	CDC	4	DTR	7	RTS
2	RXD	5	GROUND	8	CTS
3	TXD	6	DSR	9	RI

USB A Buchse:



USB 2.0 A-Buchse:				Achtung!
Pin	Signal	Pin	Signal	Stecker nie umge-
1	VCC	3	DATA+	kehrt oder mit Gewalt einstecken.
2	DATA-	4	GND	Cowart Ciriotecherii.

HARDWARE INSTALLATION:

Beachten Sie bitte die folgenden Installationshinweise. Da es grosse Unterschiede bei Computern gibt, können wir Ihnen nur eine generelle Anleitung zum Einbau der EX-1301-2F geben. Bei Unklarheiten halten Sie sich bitte an die Bedienungsanleitung Ihres Computersvstems.

 Verbinden sie nur das Ende (A-Stecker) des mitgelieferten Kabels mit der USB A-Buchse an ihrem PC.

TREIBER INSTALLATION:

Windows XP/ Vista/ 2000/ Server 2008&2003/ Win7/ 8 (32&64-Bit) :

Windows erkennt automatisch einen neuen "FT232R USB UART". Legen Sie die Treiber CD in Ihr CD-ROM Laufwerk ein (z.B. Laufwerk D:). Lassen sie nicht automatisch nach dem Treiber suchen. Sondern geben sie folgenden Pfad in das Feld "Quelldatei Pfad etc." ein. Die Treiber liegen in dem Verzeichnis

"D:\USB to IO\FTDI\(32 64bit)Win7 XP Vista 2008 2008R2 2003 2000".

ÜBERPRÜFEN DES INSTALLIERTEN TREIBERS:

Klicken Sie auf Start< >Ausführen< geben sie "compmgmt.msc" ein und klicken sie auf >OK<. Wählen sie nun >GeräteManager<. Dort müssten Sie unter "Anschlüsse (COM und LPT)" neue Einträge "USB Serial Port (COM5) bis (COM8)" und unter "Universeller Serieller Bus Controller" den Eintrag "USB Serial Converter" sehen. Wenn Sie diese oder ähnliche Einträge sehen, sind die USB Module korrekt installiert.

INSTALLATION DER PERIPHERIEGERÄTE:

Die Seriellen Ports, der USB Module können nun auf die Maximale Baudrate von 115.2Kbaud eingestellt werden. Zum Beispiel mit Doppelklick den >USB Serial Port (COM3)< öffnen. Nun können Sie die verschieden Angaben wie z.B. Baudrate, Stoppbits usw. eintragen. Die Baudrate darf nicht über 115′200 Baud eingestellt werden. Die gleichen Einstellungen können auch für die restlichen COM Ports eingestellt werden.

Windows 98/98SE/ME:

Windows findet einen neuen "FT232R USB UART". Legen Sie die Treiber CD in Ihr CD -ROM Laufwerk ein (z.B. Laufwerk D:). Lassen sie nicht automatisch nach dem Treiber suchen. Geben sie "D:\USB_to_IO\FTDI\Win98_ME" in das Feld "Quelldatei Pfad etc." ein.

ÜBERPRÜFEN DES INSTALLIERTEN TREIBER:

Klicken Sie auf Start< >Ausführen< geben sie "compmgmt.msc" ein und klicken sie auf >OK<. Wählen sie nun >GeräteManager<. Dort müssten Sie unter "Anschlüsse (COM und LPT)" neue Einträge "USB Serial Port (COM5) bis (COM8)" und unter "Universeller Serieller Bus Controller" den Eintrag "USB Serial Converter" sehen. Wenn Sie diese oder ähnliche Einträge sehen, sind die USB Module korrekt installiert.

INSTALLATION DER PERIPHERIEGERÄTE:

Die Seriellen Ports, der USB Module können nun auf die Maximale Baudrate von 115.2Kbaud eingestellt werden. Zum Beispiel mit Doppelklick den >USB Serial Port (COM3)< öffnen. Nun können Sie die verschieden Angaben wie z.B. Baudrate, Stoppbits usw. eintragen. Die Baudrate darf nicht über 115'200 Baud eingestellt werden. Die gleichen Einstellungen können auch für die restlichen COM Ports eingestellt werden.

ÄNDERN DER COM ADRESSE:

Hier können sie die Ports ändern, klicken sie z.B. auf >COM3< >Anschlusseinstellung< und >Erweitert<. Sie können dann zwischen COM3 und 256 wählen!

LINUX:

Es gibt für diese Karte Linux Treiber. Die Treiber befinden sich im Verzeichnis "D:\USB_to_IO\FTDI\Linux x86_64" auf der Treiber CD. Sie werden unter den meisten Linux Versionen unterstützt. Da sich die einzelnen Distributionen und Kernelversionen sehr von einander unterscheiden können wir ihnen leider hier keine Installationsanweisung geben. Bitte halten sie sich an die Installationsanweisung für USB Ports ihrer Linux Version.


MAC:

Es gibt für diese Karte MAC Treiber. Die Treiber befinden sich im Verzeichnis "D:\USB_to_IO\FTDI\MAC OSX oder Mac_OS_9_8" auf der Treiber CD. Sie werden unter den meisten MAC OS Versionen unterstützt. Da sich die einzelnen Versionen von einander unterscheiden können wir ihnen leider hier keine Installationsanweisung geben. Bitte halten sie sich an die Installationsanweisung für USB Ports ihrer MAC OS Version.



User Manual

Vers. 1.0 / 30.01.2013



LAYOUT:



DESCRIPTION & TECNICAL INFORMATION:

The EX-1301-2F is a plug & play high-speed USB to Serial module for USB 1.1 and 2.0 ports with one RS232 9 pin female connector. The EX-1301-2F can connect direct to the peripheral device, because he have a 9 pin female connector. The USB to Serial modules design utilizes the Chip-Set FTDI with 16C550 UART which incorporates the latest in high speed interface technology. It is not possible to change the address or IRQ settings manually, they will be obtained automatically by the system (BIOS) and operating system.

Compatibility: USB 1.1 & USB 2.0

Operating system: WIN 9.x/ ME/ 2000/ XP/ Server 2003/ Vista/ 7/ 8/ Linux/ MAC Connectors: 9Pin RS-232 female connector, 1 x USB A-Port

Extent of delivery: EX-1301-2F, manual, CD

Certificates: C€ / FCC / RoHS / WEEE
☐ DE97424562 / WHQL

JUMPER SETTING & CONNECTORS:

DB 9M:



Serial 9 Pin female connector:					
Pin	Signal	Pin	Signal	Pin	Signal
1	CDC	4	DTR	7	RTS
2	RXD	5	GROUND	8	CTS
3	TXD	6	DSR	9	RI

USB A-Connector:



USB 2.0 A-connector:					
Pin	Signal	Pin	Signal		
1	VCC	4	GND		
2	DATA-				
3	DATA+				

Attention!
Never plug in with force or in wrong direction.

HARDWARE INSTALLATION:

Because the designs of computers are different, only general installation instructions are given. Please refer your computer's reference manual whenever in doubt.

1. Connect the end from the USB cable (A-Plug) to the USB A-connector at your PC.